

POLYPROPYLENE CHEMICAL COMPATIBILITY

Chemical	Compatibility
Acetaldehyde	A ₁ -Excellent
Acetamide	A ₁ -Excellent
Acetate Solvent	B ₁ -Good
Acetic Acid	B-Good
Acetic Acid 20%	A-Excellent
Acetic Acid 80%	A-Excellent
Acetic Acid, Glacial	A ₁ -Excellent
Acetic Anhydride	B ₁ -Good
Acetone	A-Excellent
Acetyl Bromide	N/A
Acetyl Chloride (dry)	D-Severe Effect
Acetylene	A ₁ -Excellent
Acrylonitrile	A ₁ -Excellent
Adipic Acid	B ₂ -Good
Alcohols: Amyl	B ₁ -Good
Alcohols: Benzyl	A-Excellent
Alcohols: Butyl	A-Excellent
Alcohols: Diacetone	B ₂ -Good
Alcohols: Ethyl	A-Excellent
Alcohols: Hexyl	N/A
Alcohols: Isobutyl	A ₁ -Excellent
Alcohols: Isopropyl	A ₂ -Excellent
Alcohols: Methyl	A ₂ -Excellent
Alcohols: Octyl	N/A
Alcohols: Propyl	A-Excellent
Aluminum Chloride	A-Excellent
Aluminum Chloride 20%	A-Excellent
Aluminum Fluoride	A-Excellent
Aluminum Hydroxide	A-Excellent
Aluminum Nitrate	A ₂ -Excellent
Aluminum Potassium Sulfate 10%	A-Excellent
Aluminum Potassium Sulfate 100%	A-Excellent
Aluminum Sulfate	A-Excellent
Alums	A-Excellent
Amines	B ₂ -Good
Ammonia 10%	A ₂ -Excellent
Ammonia Nitrate	A-Excellent
Ammonia, anhydrous	A-Excellent
Ammonia, liquid	A ₂ -Excellent
Ammonium Acetate	A-Excellent
Ammonium Bifluoride	A-Excellent
Ammonium Carbonate	A-Excellent
Ammonium Caseinate	N/A

Ammonium Chloride	A-Excellent
Ammonium Hydroxide	A-Excellent
Ammonium Nitrate	A-Excellent
Ammonium Oxalate	A-Excellent
Ammonium Persulfate	A-Excellent
Ammonium Phosphate, Dibasic	A-Excellent
Ammonium Phosphate, Monobasic	A-Excellent
Ammonium Phosphate, Tribasic	A-Excellent
Ammonium Sulfate	A-Excellent
Ammonium Sulfite	A ₂ -Excellent
Ammonium Thiosulfate	N/A
Amyl Acetate	B ₁ -Good
Amyl Alcohol	B ₁ -Good
Amyl Chloride	D-Severe Effect
Aniline	A ₁ -Excellent
Aniline Hydrochloride	D-Severe Effect
Antifreeze	D-Severe Effect
Antimony Trichloride	A-Excellent
Aqua Regia (80% HCl, 20% HNO ₃)	B ₁ -Good
Arochlor 1248	D-Severe Effect
Aromatic Hydrocarbons	D-Severe Effect
Arsenic Acid	A-Excellent
Arsenic Salts	N/A
Asphalt	B ₁ -Good
Barium Carbonate	A-Excellent
Barium Chloride	A-Excellent
Barium Cyanide	D-Severe Effect
Barium Hydroxide	B-Good
Barium Nitrate	A-Excellent
Barium Sulfate	B ₁ -Good
Barium Sulfide	B-Good
Beer	A ₁ -Excellent
Beet Sugar Liquids	A ₁ -Excellent
Benzaldehyde	D-Severe Effect
Benzene	D-Severe Effect
Benzene Sulfonic Acid	D-Severe Effect
Benzoic Acid	B ₁ -Good
Benzol	B-Good
Benzonitrile	N/A
Benzyl Chloride	C ₁ -Fair
Bleaching Liquors	A ₁ -Excellent
Borax (Sodium Borate)	B-Good
Boric Acid	A-Excellent
Brewery Slop	N/A

Bromine	D-Severe Effect
Butadiene	C-Fair
Butane	A ₁ -Excellent
Butanol (Butyl Alcohol)	A ₁ -Excellent
Butter	N/A
Buttermilk	A ₁ -Excellent
Butyl Amine	B ₁ -Good
Butyl Ether	D-Severe Effect
Butyl Phthalate	B ₂ -Good
Butylacetate	B ₁ -Good
Butylene	N/A
Butyric Acid	B ₁ -Good
Calcium Bisulfate	N/A
Calcium Bisulfide	A-Excellent
Calcium Bisulfite	A-Excellent
Calcium Carbonate	A-Excellent
Calcium Chlorate	N/A
Calcium Chloride	A ₂ -Excellent
Calcium Hydroxide	A ₂ -Excellent
Calcium Hypochlorite	A ₁ -Excellent
Calcium Nitrate	A ₂ -Excellent
Calcium Oxide	A-Excellent
Calcium Sulfate	A-Excellent
Calgon	A-Excellent
Cane Juice	C ₁ -Fair
Carbolic Acid (Phenol)	B-Good
Carbon Bisulfide	D-Severe Effect
Carbon Dioxide (dry)	A ₂ -Excellent
Carbon Dioxide (wet)	A ₂ -Excellent
Carbon Disulfide	D-Severe Effect
Carbon Monoxide	A-Excellent
Carbon Tetrachloride	D-Severe Effect
Carbon Tetrachloride (dry)	D-Severe Effect
Carbon Tetrachloride (wet)	D-Severe Effect
Carbonated Water	B-Good
Carbonic Acid	A-Excellent
Catsup	A-Excellent
Chloric Acid	N/A
Chlorinated Glue	N/A
Chlorine (dry)	D-Severe Effect
Chlorine Water	D-Severe Effect
Chlorine, Anhydrous Liquid	D-Severe Effect
Chloroacetic Acid	C ₁ -Fair
Chlorobenzene (Mono)	C ₁ -Fair

Chlorobromomethane	A-Excellent
Chloroform	C ₁ -Fair
Chlorosulfonic Acid	D-Severe Effect
Chocolate Syrup	A ₂ -Excellent
Chromic Acid 10%	D-Severe Effect
Chromic Acid 30%	D-Severe Effect
Chromic Acid 5%	D-Severe Effect
Chromic Acid 50%	D-Severe Effect
Chromium Salts	N/A
Cider	A-Excellent
Citric Acid	A-Excellent
Citric Oils	A-Excellent
Clorox (Bleach)	A-Excellent
Coffee	A-Excellent
Copper Chloride	A-Excellent
Copper Cyanide	A-Excellent
Copper Fluoborate	N/A
Copper Nitrate	A-Excellent
Copper Sulfate>5%	A-Excellent
Copper Sulfate 5%	A-Excellent
Cream	A-Excellent
Cresols	D-Severe Effect
Cresylic Acid	A ₁ -Excellent
Cupric Acid	A ₂ -Excellent
Cyanic Acid	N/A
Cyclohexane	D-Severe Effect
Cyclohexanone	D-Severe Effect
Detergents	A-Excellent
Diacetone Alcohol	A ₁ -Excellent
Dichlorobenzene	C ₁ -Fair
Dichloroethane	D-Severe Effect
Diesel Fuel	A ₁ -Excellent
Diethyl Ether	A ₁ -Excellent
Diethylamine	A ₁ -Excellent
Diethylene Glycol	A ₂ -Excellent
Dimethyl Aniline	D-Severe Effect
Dimethyl Formamide	A-Excellent
Diphenyl	D-Severe Effect
Diphenyl Oxide	D-Severe Effect
Dyes	N/A
Epsom Salts (Magnesium Sulfate)	A-Excellent
Ethane	D-Severe Effect
Ethanol	A-Excellent
Ethanolamine	D-Severe Effect

Ether	D-Severe Effect
Ethyl Acetate	A ₁ -Excellent
Ethyl Benzoate	B ₁ -Good
Ethyl Chloride	D-Severe Effect
Ethyl Ether	D-Severe Effect
Ethyl Sulfate	N/A
Ethylene Bromide	D-Severe Effect
Ethylene Chloride	C ₁ -Fair
Ethylene Chlorohydrin	D-Severe Effect
Ethylene Diamine	N/A
Ethylene Dichloride	D-Severe Effect
Ethylene Glycol	A-Excellent
Ethylene Oxide	D-Severe Effect
Fatty Acids	A-Excellent
Ferric Chloride	A-Excellent
Ferric Nitrate	A-Excellent
Ferric Sulfate	A-Excellent
Ferrous Chloride	A-Excellent
Ferrous Sulfate	A-Excellent
Fluoboric Acid	A-Excellent
Fluorine	D-Severe Effect
Fluosilicic Acid	A-Excellent
Formaldehyde 100%	C-Fair
Formaldehyde 40%	A-Excellent
Formic Acid	A ₁ -Excellent
Freon 113	D-Severe Effect
Freon 12	A ₂ -Excellent
Freon 22	B-Good
Freon TF	D-Severe Effect
Freonr 11	A-Excellent
Fruit Juice	B-Good
Fuel Oils	A-Excellent
Furan Resin	D-Severe Effect
Furfural	D-Severe Effect
Gallic Acid	A-Excellent
Gasoline (high-aromatic)	A-Excellent
Gasoline, leaded, ref.	B-Good
Gasoline, unleaded	C ₁ -Fair
Gelatin	A-Excellent
Glucose	A-Excellent
Glue, P.V.A.	N/A
Glycerin	A-Excellent
Glycolic Acid	A-Excellent
Gold Monocyanide	N/A

Grape Juice	N/A
Grease	N/A
Heptane	C2-Fair
Hexane	B ₁ -Good
Honey	A-Excellent
Hydraulic Oil (Petro)	D-Severe Effect
Hydraulic Oil (Synthetic)	D-Severe Effect
Hydrazine	C-Fair
Hydrobromic Acid 100%	C ₁ -Fair
Hydrobromic Acid 20%	A ₂ -Excellent
Hydrochloric Acid 100%	C-Fair
Hydrochloric Acid 20%	B ₂ -Good
Hydrochloric Acid 37%	C-Fair
Hydrochloric Acid, Dry Gas	B-Good
Hydrocyanic Acid	A-Excellent
Hydrocyanic Acid (Gas 10%)	A-Excellent
Hydrofluoric Acid 100%	C ₁ -Fair
Hydrofluoric Acid 20%	A ₂ -Excellent
Hydrofluoric Acid 50%	A ₂ -Excellent
Hydrofluoric Acid 75%	C ₁ -Fair
Hydrofluosilicic Acid 100%	A-Excellent
Hydrofluosilicic Acid 20%	A-Excellent
Hydrogen Gas	A-Excellent
Hydrogen Peroxide 10%	A-Excellent
Hydrogen Peroxide 100%	B ₁ -Good
Hydrogen Peroxide 30%	B ₁ -Good
Hydrogen Peroxide 50%	B ₁ -Good
Hydrogen Sulfide (aqua)	A ₁ -Excellent
Hydrogen Sulfide (dry)	A ₁ -Excellent
Hydroquinone	A-Excellent
Hydroxyacetic Acid 70%	N/A
Ink	N/A
Iodine	C-Fair
Iodine (in alcohol)	N/A
Iodoform	N/A
Isooctane	A ₂ -Excellent
Isopropyl Acetate	B ₁ -Good
Isopropyl Ether	B-Good
Isotane	D-Severe Effect
Jet Fuel (JP3, JP4, JP5)	A ₁ -Excellent
Kerosene	B-Good
Ketones	C-Fair
Lacquer Thinners	D-Severe Effect
Lacquers	D-Severe Effect

Lactic Acid	B-Good
Lard	B ₁ -Good
Latex	A ₂ -Excellent
Lead Acetate	A ₁ -Excellent
Lead Nitrate	A ₂ -Excellent
Lead Sulfamate	A ₂ -Excellent
Ligroin	A ₂ -Excellent
Lime	N/A
Linoleic Acid	B ₁ -Good
Lithium Chloride	A ₂ -Excellent
Lithium Hydroxide	N/A
Lubricants	A ₁ -Excellent
Lye: Ca(OH) ₂ Calcium Hydroxide	A ₂ -Excellent
Lye: KOH Potassium Hydroxide	A-Excellent
Lye: NaOH Sodium Hydroxide	A-Excellent
Magnesium Bisulfate	A ₂ -Excellent
Magnesium Carbonate	A-Excellent
Magnesium Chloride	A ₂ -Excellent
Magnesium Hydroxide	A-Excellent
Magnesium Nitrate	A-Excellent
Magnesium Oxide	N/A
Magnesium Sulfate (Epsom Salts)	A-Excellent
Maleic Acid	A-Excellent
Maleic Anhydride	D-Severe Effect
Malic Acid	A ₁ -Excellent
Manganese Sulfate	N/A
Mash	N/A
Mayonnaise	N/A
Melamine	A-Excellent
Mercuric Chloride (dilute)	B-Good
Mercuric Cyanide	B-Good
Mercurous Nitrate	A-Excellent
Mercury	B-Good
Methane	A-Excellent
Methanol (Methyl Alcohol)	A ₂ -Excellent
Methyl Acetate	D-Severe Effect
Methyl Acetone	N/A
Methyl Acrylate	D-Severe Effect
Methyl Alcohol 10%	A ₂ -Excellent
Methyl Bromide	C-Fair
Methyl Butyl Ketone	D-Severe Effect
Methyl Cellosolve	B-Good
Methyl Chloride	D-Severe Effect
Methyl Dichloride	D-Severe Effect

Methyl Ethyl Ketone	B-Good
Methyl Ethyl Ketone Peroxide	N/A
Methyl Isobutyl Ketone	A-Excellent
Methyl Isopropyl Ketone	N/A
Methyl Methacrylate	D-Severe Effect
Methylamine	A ₂ -Excellent
Methylene Chloride	B ₁ -Good
Milk	B-Good
Mineral Spirits	B-Good
Molasses	B-Good
Monochloroacetic acid	N/A
Monoethanolamine	B-Good
Morpholine	B ₂ -Good
Motor oil	A ₁ -Excellent
Mustard	A-Excellent
Naphtha	B-Good
Naphthalene	B-Good
Natural Gas	A-Excellent
Nickel Chloride	A-Excellent
Nickel Nitrate	A ₂ -Excellent
Nickel Sulfate	A-Excellent
Nitrating Acid (<15% HNO ₃)	C-Fair
Nitrating Acid (>15% H ₂ SO ₄)	C-Fair
Nitrating Acid (S1% Acid)	C-Fair
Nitrating Acid (S15% H ₂ SO ₄)	C-Fair
Nitric Acid (20%)	A ₂ -Excellent
Nitric Acid (50%)	B-Good
Nitric Acid (5-10%)	A-Excellent
Nitric Acid (Concentrated)	D-Severe Effect
Nitrobenzene	B ₁ -Good
Nitrogen Fertilizer	N/A
Nitromethane	B ₂ -Good
Nitrous Acid	A-Excellent
Nitrous Oxide	D-Severe Effect
Oils: Aniline	A-Excellent
Oils: Anise	N/A
Oils: Bay	N/A
Oils: Bone	A-Excellent
Oils: Castor	A-Excellent
Oils: Cinnamon	D-Severe Effect
Oils: Citric	A-Excellent
Oils: Clove	N/A
Oils: Coconut	A ₁ -Excellent
Oils: Cod Liver	A ₁ -Excellent

Oils: Corn	A ₂ -Excellent
Oils: Cottonseed	A-Excellent
Oils: Creosote	C-Fair
Oils: Diesel Fuel•Oil(20, 30, 40, 50)	A ₁ -Excellent
Oils: Fuel•Oil(1, 2, 3, 5A, 5B, 6)	B-Good
Oils: Ginger	N/A
Oils: Hydraulic Oil (Petro)	D-Severe Effect
Oils: Hydraulic Oil (Synthetic)	D-Severe Effect
Oils: Lemon	N/A
Oils: Linseed	A-Excellent
Oils: Mineral	A-Excellent
Oils: Olive	A-Excellent
Oils: Orange	A-Excellent
Oils: Palm	N/A
Oils: Peanut	D-Severe Effect
Oils: Peppermint	N/A
Oils: Pine	B-Good
Oils: Rapeseed	D-Severe Effect
Oils: Rosin	A ₂ -Excellent
Oils: Sesame Seed	A-Excellent
Oils: Silicone	A-Excellent
Oils: Soybean	A ₁ -Excellent
Oils: Sperm (whale)	N/A
Oils: Tanning	N/A
Oils: Transformer	B-Good
Oils: Turbine	B ₁ -Good
Oleic Acid	B ₁ -Good
Oleum 100%	D-Severe Effect
Oleum 25%	D-Severe Effect
Oxalic Acid (cold)	A ₂ -Excellent
Ozone	B-Good
Palmitic Acid	B ₁ -Good
Paraffin	A ₁ -Excellent
Pentane	D-Severe Effect
Perchloric Acid	C-Fair
Perchloroethylene	D-Severe Effect
Petrolatum	D-Severe Effect
Petroleum	B ₁ -Good
Phenol (10%)	B ₁ -Good
Phenol (Carbolic Acid)	B-Good
Phosphoric Acid (>40%)	A ₂ -Excellent
Phosphoric Acid (crude)	B ₂ -Good
Phosphoric Acid (molten)	D-Severe Effect
Phosphoric Acid (S40%)	A ₂ -Excellent

Phosphoric Acid Anhydride	A-Excellent
Phosphorus	A-Excellent
Phosphorus Trichloride	N/A
Photographic Developer	A-Excellent
Photographic Solutions	A ₂ -Excellent
Phthalic Acid	A-Excellent
Phthalic Anhydride	D-Severe Effect
Picric Acid	B ₁ -Good
Plating Solutions, Antimony Plating 130°F	A-Excellent
Plating Solutions, Arsenic Plating 110°F	A-Excellent
Plating Solutions (Brass): High-Speed Brass Bath 110°F	A-Excellent
Plating Solutions (Brass): Regular Brass Bath 100°F	A-Excellent
Plating Solutions (Bronze): Cu-Cd Bronze Bath R.T.	A-Excellent
Plating Solutions (Bronze): Cu-Sn Bronze Bath 160°F	A-Excellent
Plating Solutions (Bronze): Cu-Zn Bronze Bath 100°F	A-Excellent
Plating Solutions (Cadmium): Cyanide Bath 90°F	A-Excellent
Plating Solutions (Cadmium): Fluoborate Bath 100°F	A-Excellent
Plating Solutions, (Chromium): Barrel Chrome Bath 95°F	A-Excellent
Plating Solutions, (Chromium): Black Chrome Bath 115°F	A-Excellent
Plating Solutions, (Chromium): Chromic-Sulfuric Bath 130°F	A-Excellent
Plating Solutions, (Chromium): Fluoride Bath 130°F	A-Excellent
Plating Solutions, (Chromium): Fluosilicate Bath 95°F	D-Severe Effect
Plating Solutions (Copper) (Acid): Copper Fluoborate Bath 120°F	A-Excellent
Plating Solutions (Copper) (Acid): Copper Sulfate Bath R.T.	A-Excellent
Plating Solutions (Copper) (Cyanide): Copper Strike Bath 120°F	A-Excellent
Plating Solutions (Copper) (Cyanide): High-Speed Bath 180°F	A-Excellent
Plating Solutions (Copper) (Cyanide): Rochelle Salt Bath 150°F	A-Excellent
Plating Solutions (Copper) (Misc): Copper (Electroless)	A-Excellent
Plating Solutions (Copper) (Misc): Copper Pyrophosphate	A-Excellent
Plating Solutions (Gold): Acid 75°F	A-Excellent
Plating Solutions (Gold): Cyanide 150°F	A-Excellent
Plating Solutions (Gold): Neutral 75°F	A-Excellent
Plating Solutions, Indium Sulfamate Plating R.T.	A-Excellent
Plating Solutions (Iron): Ferrous Am Sulfate Bath 150°F	A-Excellent
Plating Solutions (Iron): Ferrous Chloride Bath 190°F	C-Fair
Plating Solutions (Iron): Ferrous Sulfate Bath 150°F	A-Excellent
Plating Solutions (Iron): Fluoborate Bath 145°F	A-Excellent
Plating Solutions (Iron): Sulfamate 140°F	A-Excellent
Plating Solutions (Iron): Sulfate-Chloride Bath 160°F	A-Excellent
Plating Solutions, Lead Fluoborate Plating	A-Excellent
Plating Solutions, (Nickel): Electroless 200°F	D-Severe Effect
Plating Solutions, (Nickel): Fluoborate 100-170°F	A-Excellent
Plating Solutions, (Nickel): High-Chloride 130-160°F	A-Excellent
Plating Solutions, (Nickel): Sulfamate 100-140°F	A-Excellent

Plating Solutions, (Nickel): Watts Type 115-160°F	A-Excellent
Plating Solutions (Rhodium) 120°F	A-Excellent
Plating Solutions, (Silver) 80-120°F	A-Excellent
Plating Solutions, Tin-Fluoborate Plating 100°F	A-Excellent
Plating Solutions, Tin-Lead Plating 100°F	A-Excellent
Plating Solutions (Zinc): Acid Chloride 140°F	A-Excellent
Plating Solutions (Zinc): Acid Fluoborate Bath R.T.	A-Excellent
Plating Solutions (Zinc): Acid Sulfate Bath 150°F	A-Excellent
Plating Solutions (Zinc): Alkaline Cyanide Bath R.T.	A-Excellent
Potash (Potassium Carbonate)	A-Excellent
Potassium Bicarbonate	A-Excellent
Potassium Bromide	A-Excellent
Potassium Chlorate	A-Excellent
Potassium Chloride	A-Excellent
Potassium Chromate	A-Excellent
Potassium Cyanide Solutions	A-Excellent
Potassium Dichromate	A-Excellent
Potassium Ferricyanide	A ₂ -Excellent
Potassium Ferrocyanide	A-Excellent
Potassium Hydroxide (Caustic Potash)	A-Excellent
Potassium Hypochlorite	N/A
Potassium Iodide	A ₂ -Excellent
Potassium Nitrate	A-Excellent
Potassium Oxalate	N/A
Potassium Permanganate	A ₁ -Excellent
Potassium Sulfate	A-Excellent
Potassium Sulfide	A-Excellent
Propane (liquefied)	A-Excellent
Propylene	N/A
Propylene Glycol	A ₂ -Excellent
Pyridine	A ₂ -Excellent
Pyrogalllic Acid	A-Excellent
Resorcinal	A ₂ -Excellent
Rosins	A ₂ -Excellent
Rum	A-Excellent
Rust Inhibitors	A-Excellent
Salad Dressings	A-Excellent
Salicylic Acid	A ₁ -Excellent
Salt Brine (NaCl saturated)	A-Excellent
Sea Water	A-Excellent
Shellac (Bleached)	A-Excellent
Shellac (Orange)	A-Excellent
Silicone	A-Excellent
Silver Bromide	N/A

Silver Nitrate	A ₁ -Excellent
Soap Solutions	A-Excellent
Soda Ash (see Sodium Carbonate)	A-Excellent
Sodium Acetate	A-Excellent
Sodium Aluminate	N/A
Sodium Benzoate	A ₂ -Excellent
Sodium Bicarbonate	A-Excellent
Sodium Bisulfate	A-Excellent
Sodium Bisulfite	A-Excellent
Sodium Borate (Borax)	A ₂ -Excellent
Sodium Bromide	N/A
Sodium Carbonate	A-Excellent
Sodium Chlorate	A-Excellent
Sodium Chloride	A-Excellent
Sodium Chromate	N/A
Sodium Cyanide	A-Excellent
Sodium Ferrocyanide	A-Excellent
Sodium Fluoride	A-Excellent
Sodium Hydrosulfite	N/A
Sodium Hydroxide (20%)	A-Excellent
Sodium Hydroxide (50%)	A-Excellent
Sodium Hydroxide (80%)	A-Excellent
Sodium Hypochlorite (<20%)	A-Excellent
Sodium Hypochlorite (100%)	B-Good
Sodium Hyposulfate	N/A
Sodium Metaphosphate	A ₁ -Excellent
Sodium Metasilicate	A-Excellent
Sodium Nitrate	A-Excellent
Sodium Perborate	A-Excellent
Sodium Peroxide	B-Good
Sodium Polyphosphate	A-Excellent
Sodium Silicate	A-Excellent
Sodium Sulfate	A-Excellent
Sodium Sulfide	A-Excellent
Sodium Sulfite	A ₂ -Excellent
Sodium Tetraborate	N/A
Sodium Thiosulfate (hypo)	A ₂ -Excellent
Sorghum	N/A
Soy Sauce	N/A
Stannic Chloride	A-Excellent
Stannic Fluoborate	N/A
Stannous Chloride	A-Excellent
Starch	A ₂ -Excellent
Stearic Acid	A ₂ -Excellent

Stoddard Solvent	C-Fair
Styrene	N/A
Sugar (Liquids)	A-Excellent
Sulfate (Liquors)	A-Excellent
Sulfur Chloride	C ₁ -Fair
Sulfur Dioxide	A ₁ -Excellent
Sulfur Dioxide (dry)	A ₁ -Excellent
Sulfur Hexafluoride	N/A
Sulfur Trioxide	C-Fair
Sulfur Trioxide (dry)	D-Severe Effect
Sulfuric Acid (<10%)	A ₂ -Excellent
Sulfuric Acid (10-75%)	A ₁ -Excellent
Sulfuric Acid (75-100%)	C ₁ -Fair
Sulfuric Acid (cold concentrated)	A ₂ -Excellent
Sulfuric Acid (hot concentrated)	D-Severe Effect
Sulfurous Acid	A-Excellent
Sulfuryl Chloride	N/A
Tallow	A ₂ -Excellent
Tannic Acid	A-Excellent
Tanning Liquors	A ₁ -Excellent
Tartaric Acid	A-Excellent
Tetrachloroethane	C-Fair
Tetrachloroethylene	D-Severe Effect
Tetrahydrofuran	C ₂ -Fair
Tin Salts	A-Excellent
Toluene (Toluol)	C ₁ -Fair
Tomato Juice	A-Excellent
Trichloroacetic Acid	A-Excellent
Trichloroethane	C-Fair
Trichloroethylene	C ₁ -Fair
Trichloropropane	N/A
Tricresylphosphate	A ₁ -Excellent
Triethylamine	D-Severe Effect
Trisodium Phosphate	A-Excellent
Turpentine	D-Severe Effect
Urea	A-Excellent
Uric Acid	N/A
Urine	A-Excellent
Varnish	A-Excellent
Vegetable Juice	N/A
Vinegar	A-Excellent
Vinyl Acetate	B ₁ -Good
Vinyl Chloride	N/A
Water, Acid, Mine	A-Excellent

Water, Deionized	A ₂ -Excellent
Water, Distilled	A-Excellent
Water, Fresh	A-Excellent
Water, Salt	A-Excellent
Weed Killers	N/A
Whey	N/A
Whiskey & Wines	A-Excellent
White Liquor (Pulp Mill)	A ₁ -Excellent
White Water (Paper Mill)	A-Excellent
Xylene	B-Good
Zinc Chloride	A-Excellent
Zinc Hydrosulfite	N/A
Zinc Sulfate	A-Excellent

Explanation of Footnotes

1. Satisfactory to 72°F (22°C)
2. Satisfactory to 120°F (48°C)

Ratings: Chemical Effect

A = Excellent.

B = Good, Minor Effect, slight corrosion or discoloration

C = Fair, Moderate Effect, not recommended for continuous use. Softening, loss of strength, or swelling may occur.

D = Severe Effect, not recommended for ANY use.

N/A = Information not available.

CAUTION: Variations in chemical behavior during handling due to factors such as temperature, pressure, and concentrations can cause equipment to fail, even though it passed an initial test.